




The 3D Printing Process: How Do I *Actually* Make This?

Max J. Lerman

Department of Materials Science and Engineering, University of Maryland
Surface and Trace Chemical Analysis Group, National Institute of Standards and Technology
Center for Engineering Complex Tissues, University of Maryland

June 8th, 2017

Overview




When is 3D printing appropriate

- Rapid prototyping
 - Quick turn around → Hours to days
 - Small volumes → Dozens
 - Highly customizable → 'Soft' design



When is 3D printing appropriate

- Rapid prototyping
 - Quick turn around
 - Small volumes
 - Highly customizable
- Early design decisions
 - Internal features
 - Overhangs
 - Indents
 - Texture
 - Orientation




CECT Center for Engineering Technology



When is 3D Printing Appropriate


- Rapid prototyping
 - Quick turn around
 - Small volumes
 - Highly customizable
- Early design decisions
 - Internal features
 - Overhangs
 - Indents
 - Texture
 - Orientation
- Paper->CAD->Manufacture->Use
 - Cost
 - Time
 - Frustration



CECT Center for Engineering Technology



How to Make a Model




CECT Center for Engineering Technology

Navit Dillen, NH 3D Print Exchange




Printing Orientation

- Effect of orientation of print design on its properties
 - Mechanical strength
 - Structure stability
 - Print accuracy



VS.



Printer Selection

- FDM
- Powder Bed
- SLA/DLP
- SLS/SLM/EBM
- LOM (laminated)



invisionTEC.com



Material Selection


- Often dictated by printer selection (done in tandem)
- What is the FUNCTION of the part?
- What are the down stream applications/intended use?
 - Solubility, cleaning, cell contact, etc.
- Cost
- Available materials
 - Ceramics
 - Metals
 - Hard Plastics
 - Soft Plastics
 - Hydrogels



materialise.com



Example – DLP Bioreactor



CECT Center for Engineering Technology



Design: Background


- Design Criteria
 - Perfusion flow
 - Non-cytotoxic
 - Compact
 - Control of shear stress
 - Clear
 - Impactful 3D geometry
- Design Utilized
 - Pillared array
 - Round – to fit inside tubing
 - DLP Technology – E-Shell 300




CECT Center for Engineering Technology



CAD Generation



Imaging



Cell expansion




- Application based design
 - Single layer for imaging studies
 - Multilayered for flask replacement

CECT Center for Engineering Technology



Design Verification

- Computational modeling of design
- CFD informed flow, pillar array




CECT Center for Engineering Technology



Design Improvements

- Increased volume array
- Compact structure
- Improved connections



CECT Center for Engineering Technology



DLP Printer and Material Selection

- EnvisionTEC Perfactor 4 DLP System
 - Owned
 - Material dependent resolution (15-100 μm)
- Material options
 - All proprietary
 - Several now available
 - Limited at the time to E-shell 300





CECT Center for Engineering Technology

envisionTEC.com




DLP Fabrication



- Orient Parts
 - Support scaffold
 - Material outflow
 - Layer generation favorability
- Inspect internal pillars
- Attach to bioreactor system




Example – Biomimetic Shaped Implant




Background-Motivation

- Implantable craniofacial repair material
 - High structural complexity
 - Non-cytotoxic
 - Biodegradable
 - Vascularization
- Biomimetic Driven
 - CT



STL Generation

- Use CT scan from NIH 3D Print Exchange
- Remove excess, fragments
- Cut part down to size




CECT Center for Engineering Technology

Daryl Ricketts, NIH 3D Print Exchange



Biomimetic Shape – Material Tuning

- Develop new material
 - Compounding method
 - Printing method
 - Repeatability
- EnvisionTEC 3D Bioplotter available option




CECT Center for Engineering Technology



Biomimetic Shape – Print

- Process STL
 - Remove unwanted sections
 - Orient for printer
- Slice print file
 - Material properties
 - Overall shape
 - Generate G-code
- Post processing
- Test
 - Elution data
 - Yield and modulus
 - Cytotoxicity



CECT Center for Engineering Technology



Acknowledgements

Advisors

- Dr. John P. Fisher
- Dr. Greg Gillen

Current lab members

- Navein Arumugasamy
- James Coburn
- Dr. Ting Guo
- Megan Kimicata
- Dr. Bhushan Mahadik
- Charlotte Piard
- Javier Navarro Rueda
- Dr. Marco Santoro
- Sarah Van Belleghem
- Dr. Guang Yang
- Justine Yu

Undergraduate Researchers

- Anthony Chiu
- Anushka Gerald
- Zachary Goddard
- Madelyn Golding
- James Fookes

Collaborators

- Dr. Shin Muramoto (NIST)
- Michael Van Order (UMD)

Financial Support from
NIST MSE-2014-01



The 3D Printing Process: How Do I *Actually* Make This?

Max J. Lerman

Department of Materials Science and Engineering, University of Maryland
Surface and Trace Chemical Analysis Group, National Institute of Standards and Technology
Center for Engineering Complex Tissues, University of Maryland

June 8th, 2017

